

# Datasheet for (CO) Transmitter

## Model : COD-200 / COD-200L

---



**COD-200L (with LCD Display)**



**COD-200**

### General

COD-200 and COD-200L are the CO Transmitter which detect CO gas of the air and send signal to controller for the protect people at parking lots, Industrial working places and Buildings. COD-200 is upgraded from COD-100 to give wide reading range and better accuracy and stability.

### Features

- Semiconductor used to measure CO levels.
- Fast Response.
- 3wired / 4 wired model or with/without LCD display model is selectable
- Output mode : 4-20mA / 2-10V  
0-20mA / 0-10V
- Exclusive Compensation Algorithm is adapted.

## COD-200(L) CO Detector Specifications

### General Performance

#### Operating Temperature range

-10 ~ 50°C

#### Operating Humidity range

10 ~ 90% RH (Non-condensing)

#### Storage Temperature

-30°C ~60°C

#### Storage Humidity

10~95%RH (Non-condensing)

### CO Measurement

#### Sensing Method

Semiconductor Type

#### Measurement Range

0 to 250 ppm(0 to 100, 300 ppm is option)

#### Accuracy

At 20°C, 50%RH after 4days since power-on.

0~100ppm : ±5% FS

100~250/300 : ±10% FS

#### Response Time

< 1 minutes

#### Sampling Interval

Every 30 seconds.

#### Sensor Life Expectancy

Over 3 years

### Electrical Data

#### Power Input & Tolerance

24VDC (3-Wired) or 24VAC/24VDC ( 4-Wired)

17.5~30 V<sub>AC</sub> / V<sub>DC</sub>

### Output

#### Voltage output


2 ~ 10VDC

(0 ~100/250/300ppm, Linear output)

#### Current output

4 ~ 20mA (0~100/250/300ppm, Linear output)


### Dimensions (unit : mm)



- Size : 123.7mm x 70mm x 42.8mm  
(Length x Width x Thickness)


### Analog Voltage & Current Output and Block Diagram

Analog Voltage( V ) or Current( I ) Output




#### V/mA output Selection Method

Jumper Selection : J1



#### CO Range Selection


Jumper Selection : J7



Current output is default setting on sale.

Remark: Image is just for reference and could be changed without prior notice

#### Jumper location on PCB and Setting & Function




Jumper	Location	Setting
SW1	Right Up Side	24V/12V
J1	Left Up	Current/Voltage
J7	Center Down	Reading Range

※ Remark: Image is just for reference and could be changed without prior notice


**Wiring Method**

**4-Wired( AOUT, GND, 24V(+/-)\_AC/DC )**



※※Please make it sure to use either 24VDC+ or 24AC(+/-) power wire only on right location because the insertion into wrong location such as AOUT port brings the serious failure.

**3-Wired(AOUT, Common\_GND, +24VDC)**



※Please make it sure to use +24VDC power wire only on right location because the insertion into wrong location such as AOUT port brings the serious failure.

**Ordering Code with Option selection**

Ordering Code	LCD	3 wired or 4 wired	Remark
COD-200-4W	X	4 wired (AOUT+,AOUT_GND, 24VAC(+/-) or 24VDC)	4wired Default
COD-200L-4W	O	4 wired (AOUT+,AOUT_GND, 24VAC(+/-) or 24VDC)	+ LCD(O),
COD-200-3W	X	3wired (AOUT, Common_GND, +24VDC)	3wired Default
COD-200L-3W	O	3wired (AOUT, Common_GND, +24VDC)	+ LCD(O)

**ELT Sensor Corp.**

(ChunuiTechnopark 101-909) 36, Bucheon-ro 198beon-gil,  
 reserved. Wonmi-gu, Bucheon-si, Gyeonggi-do, 420-857, Korea  
 Phone :.82-32-719-8055

2015 ELT Sensor All rights  
 Subject to change without notice. Printed  
 2015. Oct.

Fax : 82-70-8677-8055  
<http://www.eltsensor.co.kr>